## **A**WARNING

## Before installing equipment, lock out/tag out energy source to conveyor or conveyor accessories.

Turn off and lock out/tag out energy source according to American National Standards Institute (ANSI) z244.1-1982 and Federal Register, Volume 54, Number 169, Part IV, 29 CFR Part 1910.


Refer to drawing shipped with idlers for specifications and part numbers.

### Installing Martin<sup>®</sup> Trac-Mount<sup>TM</sup> Idlers

## IMPORTANT

# Make sure all idlers in the transfer point are identical (same make and CEMA classification) to ensure proper fit.

- 1. If necessary, remove any idlers in transfer point where Martin<sup>®</sup> Trac-Mount<sup>TM</sup> Idlers are to be located.
- 2. See Figure 1. Attach track weldment to stringers using supplied hardware. Make sure track weldment is 90° to belt travel.
- 3. If necessary, attach rollers to sleeve weldments using tie tabs and hardware provided.
- 4. Slide wing weldments onto track weldment one at a time and secure with hex head cap screws, flat washers, and compression washers.



#### **Figure 1. Installing Idlers**

### Installing Martin<sup>®</sup> Trac-Mount<sup>TM</sup> Idlers in Impact Zone

- 1. Starting from point where material first impacts belt, measure back 12 in. (305 mm) toward tail pulley. Mark position on stringer.
- 2. From point marked on stringer, install idlers as explained in *Installing Martin<sup>®</sup> Trac-Mount<sup>™</sup> Idlers*, making sure track weldments are as close together as possible (see Figure 2).




Figure 2. Installing Idlers in Impact Zone

### Installing Martin<sup>®</sup> Trac-Mount<sup>TM</sup> Idlers with a Martin<sup>®</sup> Impact Cradle or Support Cradle

- 1. Install the Martin<sup>®</sup> Impact Cradle or Support Cradle according to applicable operator's manual.
- 2. Install idlers as explained under *Installing Martin<sup>®</sup> Trac-Mount<sup>™</sup> Idlers*, making sure roller is no more than 1 in. (25 mm) from either side of the impact or support cradle (see Figure 3).




Figure 3. Installing Idlers with Martin® Impact Cradle or Support Cradle



Form No. M3415-06/12 © 1998, 2012 MARTIN ENGINEERING COMPANY. All rights reserved.



One Martin Place Neponset, IL 61345-9766 USA Phone: 309-852-2384 or 800-544-2947 FAX: 800-814-1553 www.martin-eng.com

Patents and patents pending,  $\circledast$  Registered trademark of Martin Engineering Company in the U.S. and other select locations.