


MARTIN® H1 PRIMARY, P2 SECONDARY, AND R2 SECONDARY BELT CLEANER REPLACEMENT PARTS LIST



Tips




Cleaner	Part Description	Martin P/N	Flexco	Flexco Code
H1	10X3	B13-C10-005	HVT8-S/S	75419
H1	15X5	B13-C10-006	N/A	N/A
H1	25X3	B13-C10-003	N/A	N/A
H1	T 10X3	B13-C10-007	N/A	N/A
P2	V 10X3	B14-C10-003	N/A	N/A
P2	V 15X5	B14-C10-004	PSA150	73156
P2/R2	C (13X3)	C2PTC1X	ICT6	74535
R2	10X3	B15-C10-003	RSA150	73628
R2	15X5	B15-C10-002	N/A	N/A

Buffers



Cleaner	Part Description	Martin P/N	Flexco	Flexco Code
H1	55A STD SS	B13-C10-008	HFC2 *For use with SS Arms Only	75901
H1	70A HD SS	B13-C10-001	HXFC2 *For use with S-LL Arms Only	75902
P2	55A STD SS	B14-C10-001	HTSCK	76094
P2	70A HD SS	B14-C10-002	N/A	N/A
R2	55A STD SS	B15-C10-001	RSA	76249
R2	65A H SS	B15-C10-009	N/A	N/A

Arms



Cleaner	Part Description	Martin P/N	Flexco	Flexco Code
H1	HD SS	B13-C10-023	HSA8SS	73047
H1	HD S	B13-C10-024	HSA8S	73048
H1	HD M	B13-C10-025	HSA8M	73049
H1	HD L	B13-C10-026	HSA8L	73063
H1	HD LL	B13-C10-027	HSA8LL	73064