(PART NUMBER 2ND & 3RD XX'S) NUMBER OF ELEMENTS PART NUMBER PART NUMBER		(PART NUMBER LAST TWO XX'S) TENSIONER/INSTALLATION KIT REQUIREMENTS AND MATERIAL  PART NUMBER SINGLE/DUAL TENSIONER/TENSIONER SIZE/INSTALLATION KIT MATERIAL P/N INSTALLATION KIT	ITEMQTY.DESCRIPTIONPART NUMBER11MARTIN CLEANSCRAPE CLEANER ASSEMBLYSEE CHARTS
PART NUMBER DIM "A" # ELEMENTS  C1CXM <u>07</u> XRXNS4X 350 [13.78] 7 C1CXMXX <u>A</u> RXNS4X	STANDARD/MODERATE VERSION, SUITABLE FOR ABRASIVE MATERIALS AND LOW/MEDIUM BELT SPEEDS, ALLOWED FOR MECHANICAL SPLICES, HAS CHEMICAL RESISTANCE	C1CSMXXXRXNS4T SINGLE 4.2KN TENSIONER FOR 6MM CHAIN WITH FIXED POINT MNT BRKT STL C1CT4MT	
C1CXM <u>08</u> XRXNS4X 400 [15.75] 8 C1CXM <u>09</u> XRXNS4X 450 [17.72] 9		C1CSMXXXRXNS <u>4S</u> SINGLE 4.2KN TENSIONER FOR 6MM CHAIN WITH FIXED POINT MNT BRKT SS C1CT4MS  C1CBMXXXRXNS NO TENSIONER/BLADE ONLY FOR SINGLE TENSIONER WITH 6MM CHAIN	
C1CXM <u>10</u> XRXNS4X 500 [19.69] 10	BELL SPEEDS, ALLOWED FOR MECHANICAL SPLICES		
C1CXM <u>12</u> XRXNS4X 600 [23.62] 12	EXTREME VERSION, SUITABLE FOR EXTREMELY ABRASIVE MATERIALS AND HIGHEST BELT SPEEDS, NOT ALLOWED FOR MECHANICAL SPLICES		
C1CXM13XRXNS4X       650 [25.59]       13         C1CXM14XRXNS4X       700 [27.56]       14			
C1CXM <u>15</u> XRXNS4X 750 [29.53] 15 C1CXM <u>16</u> XRXNS4X 800 [31.50] 16			OLULTE WALL
C1CXM <u>17</u> XRXNS4X 850 [33.46] 17	ER 5TH X) SWAGE SLEEVES/THIMBLES MATERIAL	CHUTE WALL REFERENCE SEE INSTALLATION Π NOTE 4	CHUTE WALL—REFERENCE SEE INSTALLATION NOTE 4
C1CXM <u>19</u> XRXNS4X 950 [37.40] 19 PART NUMBER C1CXM <u>20</u> XRXNS4X 1000 [39.37] 20 C1CXMXXXRANS4X	SWAGE SLEEVES/THIMBLES MATERIAL	NOTE 4	NOTE 4
C1CXM <u>21</u> XRXNS4X 1050 [41.34] 21 C1CXMXXXR <u>C</u> NS4X	'		
C1CXM <u>22</u> XRXNS4X 1100 [43.31] 22 C1CXM <u>23</u> XRXNS4X 1150 [45.28] 23			
C1CXM24XRXNS4X       1200 [47.24]       24         C1CXM25XRXNS4X       1250 [49.21]       25			
C1CXM26XRXNS4X       1300 [51.18]       26         C1CXM27XRXNS4X       1350 [53.15]       27			
C1CXM <u>28</u> XRXNS4X			
C1CXM <u>30</u> XRXNS4X 1500 [59.06] 30		TENSIONER ASSEMBLY— / ROTATE TENSIONERS	
		TENSIONER ASSEMBLY— TYPICAL BLADE TOP/BOTTOM. SEE S50128-TD FOR OPTIONAL TENSIONER DIVERTER ARMS OBSTRUCTIONS  ROTATE TENSIONERS AS DESIRED TO CLEAR OBSTRUCTIONS	————BELT WIDTH————————————————————————————————————
	A HEAD DILLEY	TENSIONER DIVERTER ARMS /\ OBSTRUCTIONS	
	Ø HEAD PÚLLEY SEE INSTALLATION NOTE 3		
			SEE INSTALLATION NOTE 1
			SEE INSTALLATION NOTE 2
			SEE C1CP30000X FOR— BLADE EXTENSION KIT
			BLADE EXTENSION KIT
		523.0	
		[20.59]	
		SHOV	CLEANER ASSEMBLY————————————————————————————————————
	FIXED POINT————————————————————————————————————		THE HEAD PULLEY
NOTES:  1) ALL DIMENSIONS ARE GIVEN IN MILLIMETERS [INCHES].			60.0 [2.36]
1) ALL DIMENSIONS ARE GIVEN IN MILLIMETERS [INCHES]. 2) ALL DIMENSIONS ARE FOR REFERENCE ONLY. 3) IN THE "C1C" PART NUMBER: THE FIRST X INDICATES THE ASSEMBLY TYPE:	INISTALLATION NOTES.	INICTALLATION MOTEC.	[2.36] TYP
B = BLADE ONLY ASSEMBLY (NO TENSIONER) S = SYSTEM ASSEMBY WITH TENSIONER THE "M" INDICATES A "MEDIUM" CLEANSCRAPE	INSTALLATION NOTES:  1) BLADE CARBIDE SCRAPERS ARE MOLDED INTO THE RUBBER BODY AT AN ANGLE CREATING A SERRATED CLEANING EDGE. CLEANER MUST BE MOUNTED AT AN ANGLE AS SHOWN. CLEANER MUST NOT LIE IN THE	INSTALLATION NOTES:  6) ON THE OPERATORS SIDE OF THE CHUTE WALL MARK THE LOCATION OF THE TENSIONER CUTOUTS. SEE THE CUTOUT DETAIL. WELD THE TENSIONER MOUNT BRACKETS TO THE CHUTE WALL POSITIONED OVER THE CUTOUTS.  BOLT THE TENSIONERS TO THE TENSIONER MOUNT BRACKETS. LEAVE THE ADJUSTMENT BOLTS LOOSE AT THIS TIME.  7) ASSEMBLE THE CHAIN AND THE CHAIN LINKS TO THE TENSIONER END OF THE BLADE. INSTALL THE CLEANER TO THE FIXED POINT BRACKET. LEAVE THE ADJUSTMENT BOLTS LOOSE AT THIS TIME. HOLD THE CLEANER TO THE HEAD PULLEY AND ROUTE THE CHAINS THROUGH THE CHUTE WALL AND HOOK ONTO THE TENSIONERS. MAKE SURE THE TENSIONER ADJUSTMENT NUTS ARE AT THE END OF THE TENSIONER THREADED ROD. TIGHTEN THE TENSIONER ADJUSTMENT NUT UNTIL THE CLEANER IS HELD FIRMLY AGAINST THE HEAD PULLEY. ADJUST THE FIXED POINT BRACKET AND TENSIONER BRACKETS SO THE OUTER TWO ELEMENTS ON EACH SIDE OF THE CLEANER ARE APPROXIMATELY 3.3 [.13] AWAY FROM THE BELT. TIGHTEN ALL BOLTS.  8) TENSION THE CLEANER PER THE RECOMMENDED TENSION IN THE MANUAL.	TENSIONER CUTOUT——————————————————————————————————
THE M INDICATES A MEDIUM CLEANSCRAPE BLADE/SYSTEM ASSEMBLY THE NEXT XX INDICATES NUMBER OF ELEMENTS		MOUNT BRACKETS TO THE CHUTE WALL POSITIONED OVER THE CUTOUTS.  BOLT THE TENSIONERS TO THE TENSIONER MOUNT BRACKETS. LEAVE THE  ADJUSTMENT BOLTS LOOSE AT THIS TIME.	CENTERLINE
IN THE BLADE: 07 = 7 ELEMENTS THRU 30 = 30 ELEMENTS	2) THE IDEAL INSTALLATION ANGLE IS BETWEEN 17° AND 19°. ANGLES FROM 10° TO 22° ARE ACCEPTABLE BUT TENSIONER TENSION NEEDS TO BE ADJUSTED AS THE ANGLE CHANGES FROM THE IDEAL ANGLE.  3) BELT WIDTH MUST NOT EXCEED A RATIO OF 3:1 TO THE HEAD PULLEY DIAMETER. HEAD PULLEY RANGE IS 559 [22.00] MIN. TO 864 [34.00]	7) ASSEMBLE THE CHAIN AND THE CHAIN LINKS TO THE TENSIONER END OF THE BLADE. INSTALL THE CLEANER TO THE FIXED POINT BRACKET. LEAVE	AND ON THE BELT EDGE
THE NEXT X INDICATES BLADE CARBIDE TYPE:  A = A CARBIDE GRADE (MUST USE WITH COPPER  SWAGE SLEEVES)	DIAMETER. HEAD PULLEY RANGE IS 559 [22.00] MIN. TO 864 [34.00]  MAX.	THE HEAD PULLEY AND ROUTE THE CHAINS THROUGH THE CHUTE WALL AND HOOK ONTO THE TENSIONERS. MAKE SURE THE TENSIONER	
B = B CARBIDE GRADE C = C CARBIDE GRADE THE "R" INDICATES RUBBER BLADE BODY MATERIAL.	CLEANER IS TENSIONED. ADDITIONAL CHUTE WALL STRUCTURE MAY BE REQUIRED TO PREVENT CHUTE WALL FROM FLEXING.	ADJUSTMENT NUTS ARE AT THE END OF THE TENSIONER THREADED ROD.  TIGHTEN THE TENSIONER ADJUSTMENT NUT UNTIL THE CLEANER IS HELD  FIRMLY AGAINST THE HEAD PULLEY. ADJUST THE FIXED POINT BRACKET  DETAIL A	181.6 [7.15]
THE NEXT X INDICATES THIMBLE AND SWAGE MATERIAL:  A = ALUMINUM SWAGE SLEEVES & GALVANIZED THIMBLES	5) LOCATE AND INSTALL THE FIXED POINT MOUNT BRACKET ON THE INSIDE OF THE FAR SIDE CHUTE WALL. MEASURE THE HEAD PULLEY RADIUS PLUS THE LAGGING. BELT THICKNESS. AND ADD THE 12.7 [.50]. THIS	AND TENSIONER BRACKETS SO THE OUTER TWO ELEMENTS ON EACH SIDE  OF THE CLEANER ARE APPROXIMATELY 3.3 [.13] AWAY FROM THE BELT.  SCALE 3:8  TIGHTEN ALL BOLTS.	12.7
C = COPPER SWAGE SLEEVES & STAINLESS STEEL THIMBLES  (ALL C1CXMXXARCXXXXX BLADE ASSEMBLIES ARE  ONLY AVAILABLE WITH COPPER SWAGE SLEEVES	IS THE RADIUS ARĆ THAT THE FIXED POINT BRACKET WILL BE LOCATED ON. ALSO LOCATE THE FIXED POINT BRACKET LOWER MOUNTING HOLE ON THE VERTICAL CENTERLINE (AT 6:00 O'CLOCK POSITION) MARK THE	8) TENSION THE CLEANER PER THE RECOMMENDED TENSION IN THE MANUAL.	SEE NOTE 5
& STAINLESS STEEL THIMBLES) THE "N" INDICATES THE BLADE USES THE STANDARD 7X19	MAX.  4) CHUTE WALLS MUST BE STRONG ENOUGH TO NOT FLEX WHEN THE CLEANER IS TENSIONED. ADDITIONAL CHUTE WALL STRUCTURE MAY BE REQUIRED TO PREVENT CHUTE WALL FROM FLEXING.  5) LOCATE AND INSTALL THE FIXED POINT MOUNT BRACKET ON THE INSIDE OF THE FAR SIDE CHUTE WALL. MEASURE THE HEAD PULLEY RADIUS PLUS THE LAGGING, BELT THICKNESS, AND ADD THE 12.7 [.50]. THIS IS THE RADIUS ARC THAT THE FIXED POINT BRACKET WILL BE LOCATED ON. ALSO LOCATE THE FIXED POINT BRACKET LOWER MOUNTING HOLE ON THE VERTICAL CENTERLINE (AT 6:00 O'CLOCK POSITION). MARK THE HOLE LOCATIONS FROM THE FIXED POINT BRACKET AND DRILL THE MOUNTING HOLES (IF NOT WELDING IN PLACE). BOLT THE FIXED POINT BRACKET TO THE INSIDE OF THE CHUTE WALL.		60.0 TENSIONER CUTOUT TANGENT TO BELT EDGE
SS CABLE THE "S" INDICATES THE BLADE/CLEANER IS CONFIGURED FOR A SINGLE (CHAINS ON ONE SIDE) TENSIONER:	BRACKET TO THE INSIDE OF THE CHOTE WALL.		
THE NEXT X INDICATES IF AN INSTALLATION KIT			25.0
BLANK = BLADE ONLY ASSEMBLY (NO TENSIONER)  4 = MEDIUM BLADE 4.2kN COIL SPRING TENSIONER  THE LAST X INDICATES THE INSTALLATION KIT	<b>─</b> DIN	"A"	DRILL 1/2" HOLES FOR MOUNTING. LOCATE HOLES BY PLACING THE
(TENSIONER) MATERIAL: BLANK = BLADE ONLY ASSEMBLY (NO TENSIONER)		Γ1 97 <b>]</b>	FIXED POINT BRACKET LOCATION  ON FAR SIDE OF CHUTE WALL INSIDE OF THE CHUTEWALL) MTG E ON THE VERTICAL CENTERLINE SEE INSTALLATION NOTE 5  DRILL 1/2" HOLES FOR MOUNTING. LOCATE HOLES BY PLACING THE BRACKET ON THE CHUTE WALL AND MARKING THE HOLE LOCATIONS FROM IT. BRACKET MAY BE WELDED TO THE CHUTE WALL INSTEAD OF BOLTING.
T = STANDARD PAINTED STEEL S = STAINLESS STEEL		ELEMENT LENGTH	INSIDE OF THE CHUTEWALL) MTG E ON THE VERTICAL CENTERLINE SEE INSTALLATION NOTE 5  181.6  [7.15]  MARKING THE HOLE LOCATIONS FROM IT. BRACKET MAY BE WELDED TO THE CHUTE WALL INSTEAD OF BOLTING.
			TENSIONER CHUTE CUTOUTS AND FLYED DOINT REACKET LOCATION
			TENSIONER CHUTE CUTOUTS AND FIXED POINT BRACKET LOCATION  SCALE 3:16
			© Copyright 2018 Martin Engineering. All rights reserved. Covered by U.S. and foreign patents pending and issued. ® and TM indicate trademarks of Martin Engineering.
		214.3 [8.44]	MARTIN ENGINEERING-USA
	762 [30.00]		MEPONSET, IL USA
			TITLE CLEANSCRAPE DRAWN RND DATE 10/09/18
		TAHAN THE DI	CARBIDE TYPE FROM 1 & 5 TO A, FROM 15534 12/10/19 RND MEDIUM CLEANER ASM'S CHECKED WITH SINGLE 4.2kN TENS DATE 10/15/18
	<u>B</u>	ADE DETAIL SCALE 5:16	DESCRIPTION  ECN DATE BY  SALES DRAWING  APPROVED 3RB DATE 10/15/18
		SOLIDWORKS	REVISION . PR13395D S50128-M SCALE 3:16